

1384 / 1385




Quick Guide


D0134000

The escape door control terminal 1384 / 1385 can be configured individually. The operation and display may therefore differ from this quick guide.


Temporary release




Lock




Permanent release



Lock



Acknowledging an alarm (Audible signal off)



1384 / 1385




Quick Guide


D0134000

The escape door control terminal 1384 / 1385 can be configured individually. The operation and display may therefore differ from this quick guide.


Temporary release




Lock




Permanent release



Lock



Acknowledging an alarm (Audible signal off)



1384 / 1385




Quick Guide


D0134000

The escape door control terminal 1384 / 1385 can be configured individually. The operation and display may therefore differ from this quick guide.


Temporary release




Lock




Permanent release





Lock




Acknowledging an alarm (Audible signal off)




Alarm criteria




EMERGENCY-OPEN activated




Central EMERGENCY-OPEN activated




Central release



External emergency release (fire alarm system)





Tampering with terminal




Device or I/O module offline


Alarm criteria




EMERGENCY-OPEN activated




Central EMERGENCY-OPEN activated




Central release



External emergency release (fire alarm system)





Tampering with terminal




Device or I/O module offline


Alarm criteria




EMERGENCY-OPEN activated




Central EMERGENCY-OPEN activated




Central release



External emergency release (fire alarm system)





Tampering with terminal




Device or I/O module offline



Cause of the alarm



Door forced open / tampering





„Locked“ feedback missing




Door open for too long



Cause of the alarm



Door forced open / tampering





„Locked“ feedback missing




Door open for too long



Cause of the alarm



Door forced open / tampering



„Locked“ feedback missing



Door open for too long

ASSA ABLOY
Sicherheitstechnik
Bildstockstraße 20
72458 Albstadt
DEUTSCHLAND
Tel. +49 (0) 74 31 1 23 0
www.assaabloy.com/de

ASSA ABLOY
Opening Solutions

ASSA ABLOY
Sicherheitstechnik
Bildstockstraße 20
72458 Albstadt
DEUTSCHLAND
Tel. +49 (0) 74 31 1 23 0
www.assaabloy.com/de

ASSA ABLOY
Opening Solutions

ASSA ABLOY
Sicherheitstechnik
Bildstockstraße 20
72458 Albstadt
DEUTSCHLAND
Tel. +49 (0) 74 31 1 23 0
www.assaabloy.com/de

ASSA ABLOY
Opening Solutions